


# TH4-100/TH4-100-2(UL)/TH4-200

1/2

PARTS No.	NAME OF PARTS	Q'ty	PARTS No.	NAME OF PARTS	Q'ty	
AW401400	リキリツカイセ <sup>ン</sup> キバ <sup>ン</sup> 100	} 1	WE120017	ACU3X3SB SCREW	1	
	POWER FACTOR BOARD100 (FOR 100V)					
AW401500	リキリツカイセ <sup>ン</sup> キバ <sup>ン</sup> 200	} 1	WE114160	CUK3X6SA SCREW	16	
	POWER FACTOR BOARD200 (FOR 200V)			WE114105	CUK3X12SA SCREW	3
AW401600	メインキバ <sup>ン</sup> 100	} 1	WE114213	CUK4X6SA SCREW	1	
	MAIN BOARD100 (FOR 100V)					
AW401700	メインキバ <sup>ン</sup> 200	} 1	WE106069	CSK3X8SA SCREW	13	
	MAIN BOARD200 (FOR 200V)			WE106048	CSK3X16SA SCREW	5
AW401800	スイッチ	1				
AW401900	ホ <sup>リ</sup> リューム	1	WE305001	HWA3SA WASHER	3	
AW402000	ツマミ	1	WE305004	HWA4SA WASHER	1	
AW402100	ゴ <sup>ム</sup> ア <sup>シ</sup>	4				
AW402200	セ <sup>ツ</sup> エンシート	2				
AW402300	ケース	1				
AW402400	ナイフ <sup>バ</sup> ンキン	1				
AW402500	ホウネツバ <sup>ン</sup>	1				
AW402600	フロントパ <sup>ネ</sup> ル100	} 1				
	FRONT PANEL(FOR 100V)					
AW402700	フロントパ <sup>ネ</sup> ル200	} 1				
	FRONT PANEL(FOR 200V)					
AW402800	リアパ <sup>ネ</sup> ル100	} 1				
	REAR PANEL(FOR 100V)					
AW402900	リアパ <sup>ネ</sup> ル200	} 1				
	REAR PANEL(FOR 200V)					
AW403000	オサエカナク <sup>1</sup>	4				
AW403100	オサエカナク <sup>2</sup>	1				
<del>AW403200</del>	<del>メイバ<sup>ン</sup>100</del>	} 1				
AW426400	メイバ <sup>ン</sup> 100(UL)					
AW403300	メイバ <sup>ン</sup> 200					
AW403400	ホ <sup>リ</sup> リュームラ <sup>ベ</sup> ル	1				
AW403500	トラスネジ <sup>シ</sup>	4				

# 結線図 ;CONNECTING DIAGRAM



## EXPLODED PARTS DIAGRAM

MODEL	UNIT	FIG
TH4-100 TH4-100-2 (UL) TH4-200		2 / 2
<b>OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN</b>		

AV 0427, AV0416  
BINDER No.12

INDEX	No.	PARTS No.	NAME OF PARTS	Q'ty
S001	AW401800	スイッチ	SWITCH	1
U001	AW401400	リキリツカイゼンキバン100	POWER FACTOR BOARD100 (FOR 100V)	] 1
	AW401500	リキリツカイゼンキバン200	POWER FACTOR BOARD200 (FOR 200V)	
U002	AW401600	メインキバン100	MAIN BOARD100 (FOR 100V)	] 1
	AW401700	メインキバン200	MAIN BOARD200 (FOR 200V)	
V001	AW401900	ボリューム	VOLUME	1